IN260300192V01_UK

820-354V70



SMART TEMP KETTLE

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

EN

SAFETY INSTRUCTIONS

General Safety Instructions

- Read the operating instructions carefully before putting the appliance into operation and keep the instructions including the warranty, the receipt and, if possible, the box with the internal packing.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Keep the appliance and its cord out of reach of children less than 8 years.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is intended to be used in household and similar applications such as:
  – staff kitchen areas in shops, offices and other working environments;
  – farm houses;
  – by clients in hotels, motels and other residential type environments;
  – bed and breakfast type environments.
- The appliance must not be immersed.
- **WARNING** : Avoid spillage on the connector.
- **WARNING** : Potential injury may be caused from misuse.
- The heating element surface is subject to residual heat after use.
- If the kettle is overfilled, boiling water may be ejected.
- The appliance is only to be used with the stand provided.
- **CAUTION**: To prevent damage to the appliance, do not use aggressive cleaning agents when cleaning. Use a soft cloth and a mild detergent.
- **CAUTION**: Do not use the appliance if the enclosure is damaged or has visible cracks.
- **CAUTION**: Do not operate the kettle on an inclined plane. Do not switch on the kettle if there is no water in the kettle. Do not move the kettle while it is switched on.
-  **CAUTION** : Hot surfaces. Surfaces are liable to get hot during use.
- Regarding the instructions for details on how to clean the surfaces in contact with food, thanks to refer to the section "Cleaning and Maintenance".
- The appliance is designed exclusively for private use and for the envisaged purpose.

- This appliance is not fit for commercial use. Do not use it outdoors (except if it is designed to be used outdoors). Keep it away from sources of heat, direct sunlight, humidity (never dip it into any liquid) and sharp edges. Do not use the appliance with wet hands. If the appliance is humid or wet, unplug it immediately. Do not put it in water.
- When cleaning or putting it away, switch off the appliance and always pull out the plug from the socket (pull on the plug, not the cable) if the appliance is not being used and remove the attached accessories.
- Children should be supervised to ensure that they do not play with the appliance. Never leave the appliance unsupervised. To protect children from the dangers posed by electrical appliance, make sure that the cable is hanging low and that children do not have access to the appliance.
- Check the appliance and the cable for damage on a regular basis. Do not use the appliance if it is damaged.
- Do not try to repair the appliance on your own. Always contact an authorized technician. To avoid the exposure to danger, always have a faulty cable be replaced only by the manufacturer, by our customer service or by a qualified person and with a cable of the same type.
- Use only original spare parts.
- Pay careful attention to the following “Special Safety Instructions”.

Special Safety Instructions for this Machine

- Use only cold water when filling.
- The water level must be between the MAX. and MIN. marks! If the kettle is overfilled, boiling water may be ejected, which might arise a hazard to the user.
- **CAUTION**-Ensure that the kettle is switched off before removing it from its stand.
- The kettle is only to be used with the stand provided.
- The appliance must not be immersed.
- The appliance can only be used for household only.
- Always ensure that the lid is tightly closed.
- The base and exterior of the machine must not become wet.

EN

FEATURES

1. Spout
2. Base
3. Lid
4. Lid open button
5. Handle
6. Real time temperature
7. 45 degree indicator
8. 55 degree indicator
9. 75 degree indicator
10. 85 degree indicator
11. 95 degree indicator
12. 100 degree indicator
13. Keep warm
14. ON/OFF



First Use of the Machine

Please read these operating instructions carefully and keep them in a safe place. Before using for the first time, boil fresh water at least twice in the appliance. Use only water without any additives or ingredients.

OPERATION

1. Place the machine on a flat surface.
2. Open the kettle by pressing the unlocking button on the handle. Then fill in some water. The water level can be read off using the water level inside the kettle (min 0.5L, max1.5l). Please do not overfill the kettle.
3. Close the lid, place the kettle on the base, follow below instructions and choose the temperature you prefer.

   Digital live-temperature screen

   - **Real-time Temperature:** shows the actual temperature of the water in the kettle, increasing and decreasing by 1 degree;
   - **ON/OFF icon:** Touch this icon in standby mode, the kettle will directly boil water to 100°C by default; touch this icon at the preset temperature, the kettle will stop after boiling water to the set temperature; Touch it during any heating or keep warm mode, the kettle stops working and enters standby mode;
   - **Keep warm icon :** After setting the temperature, touch this icon to enter keep warm mode;
   - **Sound design:**

     a. The melodic sound only works in below four scenarios: When switching functions; When the water is boiled; When keep warm mode ends; When powered off.

     b. A single sound rings once per touch.

How to use instructions:

When powered on, all indicators and the temperature display flash 1 time at the same time, then all the indicators and the temperature display are always on, and the real time temperature in the kettle is displayed, and it enters standby mode.

Boiling mode:

Boiling 100°C operation: touch On/Off icon in standby mode, the buzzer will sound once, the temperature display and 100 degree indicator will flash 3 times at the same time and then light up and start to boil water. After the water temperature in the kettle is boiled to 100°C, the buzzer will sound twice, and the kettle will stop working and enter standby mode.

4. Keep warm:

- Under standby mode or ON mode if touching the "keep warm", you can choose 5 preset temperatures: 45, 55, 75, 85, 90 degree. During the selection, the display screen shows the temperature of the corresponding setting. The display and the corresponding indicator flashes 3 times at the same time, then lights up and the rest of the lights go out, the kettle starts to boil water.
- After the water temperature in the kettle reaches the set temperature, the buzzer sounds 2 times, then the kettle stops boiling and enters Keep warm mode. When the kettle begins to cool down and it drops to about 3°C below the set temperature, the kettle starts to boil again, and stops boiling when it reaches the set temperature. In this cycle, the corresponding setting indicator and display remain on.
- If the water in the kettle has a certain temperature at first, the selected temperature is lower than the actual one, at this time, the corresponding indicator will be flashing, and the buzzer will sound 2 times to make a special reminder. Meanwhile, the displayed temperature shows the actual temperature of the water in the kettle, when the actual temperature drops to close to the set temperature, the corresponding indicator is converted to solid, and the temperature display jumps to the set temperature.
- Keep warm time: In keep warm mode, 45, 55, 75, 85, 90 °C five temperature levels, the function of each setting will fail after accumulating 2 hours of holding time (the time of picking up the kettle halfway is not counted), all indicators will be on and enter standby mode.
- The deviation between the displayed temperature and the actual temperature in the kettle is within the range of ±5°C (the maximum water level needs to be added to the kettle, otherwise the deviation exceeds this range),

Power off

In any working state, touch the "on/off" once, the kettle enters the standby state, all indicators are always on, the temperature display is on, after 20 minutes, the temperature display and all indicators are all off, and it enters the shutdown state.

Memory function

If you lift the kettle in keep warm mode and put it back again, if the actual water temperature in the kettle is not lower than the set temperature within tolerance 5 °C (within the 2-hour period of keep warm mode), keep warm function is effective, otherwise it is invalid.

There is no memory function in the boiling mode, and the boiling mode invalidates when the kettle is lifted and put back, and the machine enters the standby mode.

Cleaning

Always pull out the plug from the socket before cleaning!

The exterior of the machine should be cleaned, if necessary, with a slightly damp cloth without additives.

Decalcification

- The frequency of the decalcify operation depends on the hardness of the water and on how often the appliance is used.
- If the machine switches off before the water boils, it probably needs to be decalcified.
- Please do not use vinegar but a commercially available decalcification agent on the basis of citric acid. Only use the quantities stated in the instructions.

SPECIFICATION

Power supply: 220-240V~50-60Hz, 2520-3000W

Off mode power	P_O	0.39	W
Standby mode power	P_{SB}	[N/A]	W
Power management function	[N/A]		
Time to enter automatically off mode	T_O	[N/A]	Min
Time to enter automatically standby mode	T_{SB}	[N/A]	Min

If you have any questions, please contact our customer care center.
Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK Ltd
1 Northampton Cross Logistics Park
Northampton Cross Road
Northampton
NN4 9FH
MADE IN CHINA

Aosom