IN260500007V01_UK

B31-657V70



15MIN

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

EN

Specification

Model	B31-657V70
Max power(Bulb)	40W
Input Voltage/Frequency	AC220-240V~ 50Hz

CAUTION

- **INDOOR USE ONLY**
- Keep out of reach of children and animals.
- Do not use in the bathroom or damp places.
- Place the lamp on a flat surface and ensure it is placed away from any flammable materials.
- Before cleaning the lamp, ensure it is switched off.
- Do not pull the plug out of the socket with wet hands.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not touch light bulb while fixture is turned on.
- Never look directly at a lit bulb.
- **Notice: Do not repeatedly turning the light on and off.**

CARE INSTRUCTIONS:

- Unplug lamp before cleaning.
- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

*** Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.**

• This product contains a light source of energy efficiency class <F>.







LED
E27(medium) base

DO NOT EXCEED THE SPECIFIED WATTAGE.

EN

Thank you for choosing our products. Please read the user manual carefully and keep it for further reference. Please follow the instructions during installation and use. The floor lamp can be controlled by the remote control or foot switch after assembled.

WARNING

1. Before assembly, lay out all parts on a clean, flat surface and inspect each part for defects that may have occurred during shipping.
2. Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have occurred during shipping. If there are any defects, DO NOT continue assembly. Please contact our customer service team immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. To reduce the likelihood of tipping over, we recommend placing the lamp behind furniture and keeping children and pets away.
5. Never drape clothes over the lamp.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and pass it along when transferring the product.

Specifications

Lamp	
Material	Iron + Fabric
Socket Type	E27
Switch	Foot switch + Remote control
Product Height	160cm
Bulb	
Input Voltage	AC220-240V 50/60Hz
Dimmable	Yes
Color Temperatures	3000K -6000K

EN

Package List



A.Lampx1



B. Remote Control x 1



C. Top Bracket x 1



D. Bottom Bracket x 1



E. Bulb x 1



F. Lampshade x 1

G.Nut x1



H. Base x 1



I. Round wooden board x 1

G. polex1

EN

NOTE: The lamp nut is on the lamp holder and needs to be unscrewed.



Assembly

① Connect the straight pole to the U-shaped pole.

② → ③→ ④: Connect each pole in sequence from bottom to top.

⑤ Connect the U-shaped pole to the base.

⑥ Connect the straight pole to the U-shaped pole.

⑦ Connect the wooden board to the straight pole.

⑧ Press the Velcro fasteners at both ends of the lampshade together.

⑨ → ⑩: Clip the bracket to the lampshade;

⑪ Unscrew the nut from the lamp holder (keep it aside for attaching the lampshade).

⑫ Install the assembled lampshade to the lamp holder, lock the lampshade on the lamp holder with the lamp nut;

⑬ Install the light bulb to complete the assembly.

EN

Use Tips for the Remote Control

On/off: 1. Step on/off the foot switch 2. If you want to control by the remote controller, please step on the foot switch first.

Color Temperature: Press the "– / + " button.

Short Press: grading adjustment; Long Press: stepless adjustment.

Brightness: Press the "– / +" button.

Short Press: grading dimming; Long Press: stepless dimming.



EN

Check if the remote works:

Install the battery (not included) into the remote. Plug to the power supply and check if every button works well.

If the remote control doesn't work for the lamp, please check whether the indicator light lights up or not. If it is on, please try to match the code (refer to "Matching Process").

If it still doesn't work, please clear the code (refer to "Code-clearing Process") and match the code again. Or please contact us immediately.

Matching Process:

1. Connect the power supply and turn on the lamp.
2. Within 1 minute of power-on, press the power button of the remote and hold on around 3 seconds.
3. When the light flashes, it matches successfully.



EN

Code-clearing Process:

Switch on and off the foot switch for 5 rounds (step 10 times). When the main light flashes, it means clear the code successfully.



UK

If you have any questions, please contact our customer care center.
Our contact details are below:

0044-800-240-4004

enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK Ltd
1 Northampton Cross Logistics Park
Northampton Cross Road
Northampton
NN4 9FH
MADE IN CHINA

Aosom